

PROFIX®

www.profix.com.pl

PL PILARKA UKOSOWA


GB MITRE SAW

RU УГЛОТОРЦОВОЧНАЯ ПИЛА

TRYTON

ELEKTRONARZĘDZIA

TU1450



2020-01-23

Part No	Art No	Pc	EN Description	PL Opis	RUS Описание
1			Upper Arm		
2			Cable Holder		
3			Nut M5		
4			Nut M6		
5			Screw M5X16		
6			Knob M6X45		
7			Screw M4X8		
8	YTU05008		Transformer	Transformator	Трансформатор
9			Cable Sleeve		
10			Cable Holder		
11			Tapping Screw ST4.2x16		
12			Cable		
13			Screw M5X12		
14			Spring Washer Ø5		
15			Flat Washer Ø5		
16			Screw M5X35		
17			Handle		
18			Tapping Screw ST4.8x40		
19			Upper Handle		
20			Terminal Block		
21			Capcaitor 0.33 µF		
22			Trigger		
23			Spring		
24	YTU05024		Switch	Włącznik	Включатель
25			Tapping Screw ST4.2x16		
26	YTU05026		Laser switch	Włącznik lasera	Включатель лазера
27			Stopper		
28			Lower Handle		
29			Brand Label		
30			Screw		
31			Screw M5X12		
32	YTU05032		Shaft Lock Bar (new)	Blokada wrzeciona	Блокировка шпинделя
33	YTU05033		Rotor	Wirnik silnika	Якорь электродвигателя
34			Bearing Bush		
35			Fan shroud		
36	YTU05036		Stator	Stojan silnika	Статор электродвигателя
37			Motor Housing		
38			Brand Label		
39			Screw M5X30		
40	YTU05040		Carbon brush holder	Szczotkotrzymacz	Щеткодержатель
41			Carbon brush cover		
42	YTU05042		Carbon brush	Szczotka węglowa	Угольная щетка
43			Screw M5X8		
44			Tapping Screw ST4.8x55		
45			Flat Washer Ø4		
46			Ball Bearing 608-2Z		
47			Ball Bearing6200-2Z		
48			Screw M5X40		
49			Lower Guard Lock Base		
50			Screw M5X12		
51			Lower Guard Lock Button		
52			Nut M5		
53			Spring		
54			Screw		
55	YTU05055		Gearbox Assembly	Przekładnia	Редуктор
55.01			Screw M4X10		
55.02			Bearing Cover		
55.03			Output Spindle		
55.04			Flat Key 4x4x10		
55.05			Ball Bearing 6002-2Z		

55,06			Bearing Seat		
55,07			Wave washer Ø12		
55,08			Gear		
55,09			Spring Ring Ф12		
56	YTU05058		Inner flange	Podkładka wewnętrzna tarczy	Внутренний фланец диска
57			Saw blade Ø210mm	Piła tarczowa Ø210mm	Диск пильный Ø210мм
58	YTU05058		Outside flange	Podkładka zewnętrzna tarczy	Наружный фланец диска
59	YTU05060		Flat washer	Podkładka płaska	Плоская шайба
60			Screw M8X20 (left)	Śruba M8X20 (lewy gwint)	Болт М8Х20 (левая резьба)
61			Screw M4X8		
62			Nut M8		
63			Flat Washer Ø8		
64			Turntable Insert		
65			Screw M4X12		
66			extension rod		
67	YTU05067		Guard&Linkge Plate Ass.	Ośłona tarczy	Защитный кожух
67,01			ScrewM5x20		
67,02			Washer		
67,03			Rivet Ø4X12		
67,04			Lower Guard Stationery Plate		
67,05			Spring		
67,06			Linkage Metal Round Plate		
67,07			Lower Guard Stationery Plate		
67,08			Linkage Plate B		
67,09			Rivet		
67,10			Lower Guard Rotatable Plate		
67,11			Linkage Plate A		
67,12			Lower Guard Transparent Part		
67,13			Lower Guard cover		
67,14			Roller		
67,15			Washer4		
67,16			Tapping Screw ST4.2x8		
67,17			Linkage Plate C		
68			Turntable Assembly		
68,01			Mitre Lock Knob		
68,02			Mitre Lock Shaft		
68,03			O-ring Ø6		
68,04			Mitre Lock Release Knob		
68,05			Mitre Positioning Shaft Spring		
68,06			Mitre Positioning Shaft		
68,07			Round pin Ø3×18		
68,08			Front support base		
68,09			Nut M8		
68,10			Hex Bolt M8X18		
68,11			Screw M4x12		
68,12			Spring Washer Ø4		
68,13			Mitre Lock Rear Seat		
68,14			Miter Lock Friction Plate		
68,15			ScrewM4x16		
68,16			Turntable		
68,17			Spring		
69			Base		
70			Mitre Pointer		
71			Hex Bolt M8X30		
72			Wave Washer φ8		
73			Base Rubber Feet		
74			Lock Release KnobM6X35		
75			Nut M6		
76			ScrewM5X20		
77			Roller Cover		
78			Screw		
79			Active plate		

80		Bevel Scale		
81		Screw M6x12		
82		Pivot Support		
83		Workclamp Assembly		
83,01		Workclamp Screw Rod		
83,02		Workclamp Base		
83,03		Workclamp Bowl		
83,04		O-ring Ø4		
83,05		Workclamp Shaft		
83,06		Small Knob M6X12		
83,07		Cover		
84		Bevel Bearing		
85		Screw M6x25		
86		Flat Washer Ø6		
87		Screw M5x12		
88		Bevel Pointer		
89		Screw		
90		Pivot Assembly		
90,01		Screw M4X8		
90,02		Rubber Ring		
90,03		Upper sliding linear bearing cover		
90,04		Screw M6x40		
90,05		Nut M6		
90,06		Bevel		
90,07		Screw M6x40		
90,08		Linear Bearing Φ25×Φ40×35		
90,09		Spring		
90,10		Lock Release KnobM6X20		
91		Flat Washer Ø10		
92		Nut M10		
93		Screw		
94		Wrench		
95		Spring		
96		Screw		
97		Screw M5x8		
98		Cable Holder		
99		Screw M4X8		
100		Sliding Bar cover		
101,01		Laser		
101,02		Upper sliding front base		
101,03		Upper sliding front base cover		
101,04		Screw M4x8		
101,05		Screw M4x10		
101,06		Sliding Bar (406mm)		
101,07		Wave Washer Ø5		
101,08		Depth Adjusting Block		
101,09		Screw		
101,10		Pin		
101,11		Screw M5x8		
101,12		Screw M4x12		
102		O-ring Ø6		
103		O-Ring 5X1.8G		
104		UpperArm Lock Pin		
105		UpperArm Spindle		
106		Torque Spring		
107		Screw M5x8		
108	YTU05108	Fence	Płyta oporowa	Параллельный упор
109		Small KnobM6X12		
110		Screw M6x25		
111		Screw M5x12		
112		Safety Block		
113		Screw M5x16		
114		Screw M5x10		